

Installation Instructions for 2003 and Up GM 4L60E Transmission Harness

1. Remove old wire harness from valve body.
2. Install new Rostra wire harness.
Note: Bolt locations may differ from old harness.
3. Plug-in connectors as shown in figure below.

CAUTION: Care must be taken when re-installing pan to prevent pinching wires.

ON/OFF LOCK-UP
RED/BLACK WIRES

3/2 DOWNSHIFT
GRAY CONNECTOR
RED/WHITE WIRES

PRESSURE SWITCH
WHITE FIVE-PIN CONNECTOR
BROWN/GRAY/PURPLE/
ORANGE/BLUE WIRES

SHIFT SOLENOID A
WHITE CONNECTOR
RED/GREEN WIRES

SHIFT SOLENOID B
WHITE CONNECTOR
RED/YELLOW WIRES

PWM LOCK-UP
BLUE CONNECTOR
RED/BROWN WIRES

EPC (FORCE MOTOR)
GRAY CONNECTOR
PURPLE/BLUE WIRES

